



Clean the upper edge of the truck bed in order to have a clean and even surface. Place the aluminium U-profile onto the bulkhead of the truck bed.

**Fasten the U-profile with the supplied M8 screw.
Note: We recommend to use Loctite 243 threadlocker.**



Hard Tri-fold Cover Installation Guide

Tri-fold hard tonneau cover

Parts List:	Assembled Tri-fold hard Cover	1 pc
	Locking pin	4 pcs

Step 1

Place assembled cover over cab end of truck box

Step 2

Unfold the cover fully and adjust position over the truck bed for proper alignment on cab/tail

Step 3

Carefully refold the cover without shifting its position on the truck bed

Step 4

Secure the Front Clamps (left and right) by pulling the clamp handle down to clamp the metal bed wall edge of truck. Note: If necessary, adjust the clamp position by rotating the clamp on the bolt to ensure the clamp is tightly clamped on the metal bed wall edge of truck. Do not secure to only lip of bedliner or rail cap.

Step 5

Insert locking pins into front clamps



Step 6

With truck tailgate open and front clamps secure, completely unfold the cover. Repeat Step 4 and 5 on the two rear clamps.

To open the cover:

Release the rear clamps, fold the cover forward.

Note 1): when folding the cover, make sure to push down & lock the rear clamps into the cross bar.



2): When cover is folded completely, secure the folded cover by fastening the straps with buckles together. Pull the straps to tighten the folded cover tightly.

Attention:

Never Drive with a cover in partially opened position. When driving, cover must be secured with 4 clamps or completely folded up and secured by front clamps and buckles.